



**REQUIRED HOLES ON FACE OF DOOR**

- 1) DRILL 1 1/4" (32) CYLINDER HOLE (A-0S) ON OUTSIDE OF DOOR
- 2) DRILL 1/2" (12.7) HOLE (B) ON INSIDE OF DOOR

NOTE: TAILPIECE MOUNTING HOLE LOCATIONS VARY DEPENDING ON THE TAILPIECE. INSTALL AND DRILL MOUNTING HOLES FOR TAILPIECE AFTER LOCK BODY IS INSTALLED IN THE DOOR



Brookline Industries  
1624 South Clinton Street  
Chicago, IL 60616 USA  
<http://brooklineind.com>

DIMENSIONS ARE INCHES ( ) ARE IN MILLIMETERS.

**A660 DEADBOLT CYLINDER X TURN FOR WOOD DOORS**

TEMPLATE NUMBER: **T-A660W Rev1**

DATE: 01-01-2006